



Being that our brick is exteriorly decorated and not body through, chipping will expose the base color.

If this is something that is not to the liking of the customer, a simple remedy can be implemented during the bricklaying process.



SMEAR TECHNIQUE PROCEDURES

This technique is accomplished by smearing the excess mortar that squeezes out within lines of brick, onto the chipping to cover it up.

To get a natural and uniform look, smearing must be done **DURING** bricklaying, **NOT** after.

TOOLS NEEDED

To achieve uniformity throughout the brick wall, the mason must use the appropriate tools to perform the smearing.

We recommend using a 4x8" piece of floor carpet, folded in half .
Alternatively the mason could use a piece of thick burlap fabric, in the same 4x8" size.