



Although extremely similar to Full Brick in its final look and feel, the installation of Thin Brick is vastly different to that of Full Brick. Rather than being laid on a Foundational Ledge, Thin Brick is installed directly onto the structure of the building.

As a result of this, the structure of the building bears the full load of the Brick. In order to ensure the longevity of the install, as well as prevent future structural damage to the building, installers must follow the subsequent instructions during the application of our Thin Brick .

1.) DIMPLE MAT INSTALLATION

Install a Dimple Mat onto the Sheer Wall of the building where Thin Brick will be applied.

2.) SCRATCH COAT APPLICATION

Apply a layer of Scratch Coat Plaster onto the Dimple Mat.

3.) BROWN COAT APPLICATION

Apply a layer of Brown Coat Plaster over the layer of Scratch Coat.

4.) THIN BRICK INSTALLATION

Using Thin Set rated for outdoor use, adhere the Thin Brick to the Brown Coat Layer.

5.) MORTAR APPLICATION

Once the Thin Set has cured, apply mortar to the gaps between the brick. Use the color and finish of mortar needed to achieve the desired finish.

If you have any questions regarding the installation process, please reach out to your Old Texas Brick representative for more information.