



WHAT IS IT?

Vanadium Efflorescence is a temporary natural yellowish / green stain that forms on the face of clay products.

HOW DOES IT SPROUT?

Vanadium Efflorescence sprouts when the elements found in rain water come in contact with the minerals found in masonry products.

Vanadium Efflorescence is most prevalent when construction is done during months of High Humidity. In combination with excessive rainfall, the humidity in the environment causes Vanadium Efflorescence to Sprout.

HOW IS IT REMOVED?

Vanadium Efflorescence can wear away naturally within a few months, but if quicker solution is needed, a cleaning product can be applied.

Old Texas Brick recommends the use of PROSOCO's Sure Klean 800.

If used, please follow the instructions listed on the cleaning products label.

Once Sure Klean 800 has been applied, you can expect staining to wear away within a few weeks.

HOW CAN I PREVENT IT?

In order to prevent Vanadium Efflorescence, all incomplete walls must be covered to protect brick from rainfall.

Additionally, any Brick Pallet that no longer has its manufacturer applied shrink wrap must be covered to protect brick from rainfall.